

**FCC Warning**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference, and  
 (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:  
 - Reorient or relocate the receiving antenna.  
 - Increase the separation between the equipment and receiver.  
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 - Consult the dealer or an experienced radio/television technician for help.

**NOTE 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**RF Exposure Statement**  
 To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its accessories must not be co-located or operated in conjunction with any other antenna or transmitter.

**NOTICE TO USERS**

-Please pay attention to the Space Capsule Smart Cat Litter Box, we keep working to bring you great products.  
 -Please read the product manual carefully before use, installation or use indicates acceptance of the safety guidelines.  
 -Any accidents or losses due to improper operation will not be our responsibility, and we assume no legal liability.  
 -The right to inspect and amend this statement belongs to our company.

# <T<HUI

**SPACE CAPSULE SMART CAT LITTER BOX**

**USER MANUAL**




Read the user manual carefully before use and keep it for future reference.


**Table of Contents**

- I. Product Packaging List ----- 01
- II. Product Introduction ----- 02
- III. Installation Instructions ----- 04
- IV. Product Usage Instructions (Binding App / Network Setup) ----- 06
- V. Garbage Bag Change ----- 08
- VI. Cleaning and Maintenance ----- 10
- VII. Fault Indicator Light Explanation ----- 11
- VIII. Protection Function ----- 11
- IX. Working Mode Introduction ----- 12
- X. Precautions ----- 13
- XI. Basic Parameter Information ----- 14
- XII. Toxic and Harmful Substances ----- 14
- XIII. Safety Guidelines for Use ----- 15
- XIV. After-Sales Service Card ----- 16

**I. Product Packaging List**



Main Unit



Power adaptor    Manual    Garbage Bag

01

**II. Product Introduction**

**Introduction to the Keypad Functions**

- Wi-Fi**  
Network Configuration  
- Press the Wi-Fi button for 3 seconds. Blue light flashes when power is on. (Blue light stays on for 10 seconds. 2 dots on Wi-Fi only.)
- Sand Grooming/Sand Replacement**  
- Single short press (grooming): Start or pause grooming. Blue light stays on during grooming and turns off when done.  
- Hold for 3s (sand replacement): Blue light flashes during sand replacement. Single short press resumes. Light off when done.
- Manual cleaning/Bag changing**  
- Single short press (cleaning): Start or pause manual cleaning. Blue light stays on during cleaning and turns off when done.  
- Hold for 3s (bag change): Blue light flashes during bag change. Single short press resumes. Light off when done.
- Child lock**  
- Long press (3s) for 3 seconds. Blue light flashes during process and turns off when done. (During operation, a single short press can pause or resume the process.)




Reset Factory Settings  
Wi-Fi + Clean button  
Hold for 5s



03

**III. Installation Instructions**

**1. Install the main body.**

04

**2. Bag in box.**  
- Ensure the garbage bag bottom fits the waste bin bottom.

**3. Add cat litter.**  
- Do not add cat litter above the height of the anti-stick pad.  
- Litter length: 15mm, weight: ±25kg, about 4L.


**4. Plug in the power.**  
- Use the DC power cord provided with the litter box.  
- The device will turn on automatically when plugged in.

After power on, self-check starts. Status light flashes white. After self-check, status light stays on. Wi-Fi light flashes blue for setup.

05

**IV. Product Usage Instructions**

**1. App Binding/Networking** - Wi-Fi



**1 Scan QR code to install app and set up network.**  
Scan camera QR code to download app. Register and add device via Wi-Fi to bind smart litter box.


**2 Long press "Wi-Fi" Button**  
Hold Wi-Fi button for 3 seconds to enter setup mode. Blue light flashes. (If setup fails, hold Wi-Fi button again to retry.)

Select the little Wisdom Cat Litter box and start using it.

06

**1 App Interface**

In the app interface, you can set the suitable mode or parameters according to your cat's situation.



07

**2. Sand Grooming**

Press "S" button once to start the sand grooming process. Blue light stays on during grooming. Turns off when done.




**3. Sand Replacement**

**1** Before replacing the cat litter, please ensure that the waste bin is empty and replace the garbage bag.

**2** Long press "S" 3 seconds. Execute the one-key sand change function.

08

**V. Garbage Bag Change**

09

**VI. Cleaning and Maintenance**

For your cat's health, it is recommended to clean and maintain the device regularly.

**1. Cleaning**

**Washable** (Drum and Litter Pad)  
**Not Washable** (Base and Motor)

Dry or air-dry after washing, then use.  
 Don't wash the base. Wipe with a cloth.

There is a circuit board in the base. Please keep it away from water sources and wipe the surface in a dry and ventilated environment.

\*Avoid using alcohol, disinfectants, bleach, or other non-neutral cleaning solutions.

10

**VII. Fault Indicator Light Explanation**

- 1. When the device is powered on, the white light stays on in normal standby mode.
- 2. When child lock is on, blue light stays on.
- 3. When the device detects a cat or person approaching, the red light will flash continuously, regardless of whether it is in standby or child lock mode, until the pet leaves, at which point it will return to the current instruction prompt state.
- 4. When the device is interrupted due to power, blockage, or other reasons during the current instruction for cleaning, sand replacement, or sand grooming, the red light stays on.

**VIII. Protection Function**

**1 Radar protection (Level 1)**  
- Object approaches: Radar protection triggers, drum stops.  
- When the object is still or leaves, the drum will resume rotation.

**2 Weight protection (Level 2)**  
- Object adobe in drum: Weight protection triggers, drum stops.  
- When the weight is gone, the drum will start again.

**3 Motor stall protection (Level 3)**  
- Drum stops if motor resistance increases during rotation. Manual reset needed.

**4 Anti-pinch protection (Level 4)**  
- Innovative design ensures no risk of pinching cats even if all sensors fail.


11

**IX. Working Mode Introduction**

**1 Automatic Mode**  
After the cat uses the litter box and leaves the drum, the system will automatically start the cleaning mode based on the set interval time until the cleaning is completed.

**2 Manual Mode**  
Pressing the device button or the APP button can both control the start and pause of the cleaning function.

**3 Do Not Disturb Mode**  
Set the Do Not Disturb period via the app to mute notifications.



12

**X. Precautions**

Carry by holding both sides. Opening the Lid During Operation

**1** When moving the product, please lift it from the base. Do not move the drum directly.

**2** Do not open the waste bin cover while the device is running to avoid damage. Do not force - operate or touch the device while it is running.

13

**XI. Basic Parameter Information**

Product Name	Space Capsule Smart Litter Box					
Product Model	SLB-A					
Product Dimensions	500x530x508mm					
Total Weight	~9kg					
Rated Input	12V 2A					
Connection	Wi-Fi					
Applicable Range	Cats over 6 months old					

**XII. Toxic and Harmful Substances**

Part Name	Hazardous substances or elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Cr(VI) (Cr6+)	PBBs (PBB)	PBDEs (PBDE)
PCBA	×	○	○	○	○	○
Plastic	○	○	○	○	○	○
Metal	○	○	○	○	○	○
Attachment	○	○	○	○	○	○

14

**XIII. Safety Guidelines for Use**

"Non-compliance may cause product malfunction or other losses."

- Please strictly follow the instructions for installation and use of the equipment.
- Do not use for kittens under 6 months old or cats weighing less than 1.5 kg.
- Do not place the device in a high-temperature or high-humidity environment.
- For indoor use only. Do not place in direct sunlight or near a heat source.
- This product uses safe low-voltage power, but pets chewing on the power cord can still cause a leakage risk. Please secure and hide the power cord during use to prevent pets from chewing on it. If you notice your pet chewing on the cord, stop it immediately.
- Use only the original adapter; otherwise, it may damage the device or create safety hazards.
- Place on a flat, hard surface and avoid contact with walls.
- Do not tilt the device to avoid safety hazards.
- Do not immerse or soak the bottom of the device in water.
- The bottom of this product contains a weight sensor. Please handle with care when moving it.
- Unplug power cord when not in use or moving.
- If children use this device, make sure they do so under adult supervision.
- Have repairs done by a professional to avoid accidental injuries.
- Don't place objects on or press the device top to ensure normal operation.
- Before a long holiday, ensure the litter in the smart cat toilet is sufficient and the waste bin has enough space.
- If you encounter any product usage issues, please contact customer service promptly.

15

**XIV. After-Sales Service Card**

**Warranty Terms**

During the warranty period, non-human damage causing product performance failure is covered by the three guarantees:

1. Within 1 year of purchase, if the waste removal product has quality issues, the consumer can choose a replacement of the same price or a replacement with the same model and specification.  
 2. Within 1 year of purchase, if the waste removal product has quality issues, the consumer can choose to replace it with the same model and specification.  
 3. The warranty period for this product is one year.  
 4. This certificate shall not be altered, otherwise, it will be deemed invalid.  
 5. This certificate becomes valid only after being stamped by the selling unit.

**Non-warranty Terms**

The following situations (but not limited to) are not covered by the "Three Guarantees":

1. The "Three Guarantees" (replacement, repair, or refund) do not apply to the waste removal product, or exceeding the "Three Guarantees" service validity period.  
 2. Damage caused by force majeure such as fire, lightning strike, flood, etc.  
 3. Damage caused by force majeure such as fire, lightning strike, flood, etc.  
 4. The product model or serial number on the warranty card does not match the actual product.  
 5. Damage caused by disassembly or repair by non-authorized service providers.  
 6. Normal fading, wear, and consumption during product use are not covered warranty-covered faults.

16

**Maintenance Record**

Repair Center Name: \_\_\_\_\_ Repair Fault Condition: \_\_\_\_\_  
 Repair Center Phone: \_\_\_\_\_ Refund/Return Proof: \_\_\_\_\_  
 Repair Date: \_\_\_\_\_ Technician's Signature: \_\_\_\_\_  
 Fault Cause: \_\_\_\_\_ Repair Center Stamp: \_\_\_\_\_

To ensure effective after-sales service, please fill out the Product Warranty Card truthfully after purchase and keep it properly.

17