



# iCam365 Quick Start Manual

WIFI CAMERA


2023




Please be sure to scan the QR code above to download "iCam365" APP



## A Connect the device




**Download the app**  
Use the "Scan" function of your mobile phone to scan the QR code, download and install the "iCam365" APP



**Connect power**  
Connect the device to the power supply and wait for about 1 minute

## B Add device




01.log in



02.Add device




03.Scan the QR code of the fuselage




04.Waiting for a automatic recognition




05.Select the WiFi to connect to and enter the password



06.Waiting to configure the network






09.The addition is complete, the device is named



The device will appear on your homepage

## C Function Description



## D Common problem

Problems	Solution
What should I do if the device is unsuccessfully added?	Check whether the WiFi password is correct, and the network can be connected correctly, then RESET the camera, and add it again after completion.
How to download video?	Click the "Record Screen" button during playback, and click the red button after recording, and the video file will be saved to the phone;
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still disconnected after restarting,
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please restart the camera.2. The memory card is still not recognized after restarting the camera, please replace with a new card and test again.3. If the new card is still not recognized, the card slot may be damaged or the cable is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings and check whether the message push is turned off in the device settings. Alarm messages are stored for up to 7 days